

## general mounting instructions for front strut bars

Front strut bars you have to install on the available fixtures on the wheel housing domes:

- Vehicle remains on the floor (Don't lift it!).
- Remove the nuts from the stud bolts on the wheel housing domes.
- Loosen the screws left and right on the brackets from the front strut bar when it is a 3-pieces strut bar.
- Put the front strut bar on the wheel housing domes.
- Fasten the brackets with the nuts from the stud bolts (torque according to manufacturer's instructions).
- Pull the screws left and right on the brackets from the front strut bar tight when it is a 3-pieces strut bar (torque 44 Nm).

Front strut bars where you have to drill holes for the installation:

- Put the front strut bar on the wheel housing domes.
- Bait the holes central.
- Drill the holes and deflash / cut it.
- Conserve the drill holes.
- Install the front strut bar with our mounting material (torque 24 Nm).