

## general mounting instructions for rear strut bars

Rear strut bars you have to install on the available fixtures on the wheel housing domes:

- Vehicle remains on the floor (Don't lift it!).
- Remove the nuts from the stud bolts on the wheel housing domes.
- Loosen the screws left and right on the brackets from the rear strut bar when it is a 3-pieces strut bar.
- Put the rear strut bar on the wheel housing domes.
- Fasten the brackets with the nuts from the stud bolts (torque according to manufacturer's instructions).
- Pull the screws left and right on the brackets from the rear strut bar tight when it is a 3-pieces strut bar (torque 44 Nm).

Rear strut bars where you have to drill holes for the installation:

- Put the rear strut bar between the wheel housing domes (approximately 20 cm from the floor of the boot high to the wheel housing domes / vehicle significant).
- Bait the holes central.
- Drill the holes and deflash / cut it.
- Conserve the drill holes.
- Install the rear strut bar with our mounting material (torque 24 Nm).